



Photovoltaic Grid-connected Microinverter (Built-in WIFI-G3)



Installation/User Manual

SUN300G3-EU-230, SUN500G3-EU-230, SUN600G3-EU-230, SUN800G3-EU-230,
SUN1000G3-EU-230, SUN1300G3-EU-230, SUN1600G3-EU-230,
SUN1800G3-EU-230, SUN2000G3-EU-230

Global Tech China Ltd, 3 Floor, Wai Yip Industrial Building.171 Wai Yip Street,
Kwun Tong, Kowloon, Hong Kong.

Tel: +852 2884 4318 Fax: +8522884 4816

www.sunsynk.com / sales@globaltech-china.com / www.globaltechhk.com

INDEX

<u>1. IMPORTANT SAFETY INSTRUCTIONS</u>	4
1.1. RADIO INTERFERENCE STATEMENT	5
1.2. SYMBOLS.....	5
<u>2. MICROINVERTER SYSTEM INTRODUCTION</u>	6
2.1. MICROINVERTERS MAXIMIZE PV ENERGY PRODUCTION.....	7
2.2. MORE RELIABLE THAN CENTRALIZED OR STRING INVERTERS	7
2.3. INSTALLATION - SIMPLICITY	8
<u>3. MICROINVERTER INTRODUCTION</u>	8
<u>4. MICROINVERTER SYSTEM INSTALLATION</u>	8
4.1. ADDITIONAL INSTALLATION COMPONENTS	9
4.2. REQUIRED PARTS AND TOOLS (USER SUPPLIED)	9
<u>5. INSTALLATION PROCEDURES</u>	9
<u>6. MICROINVERTER SYSTEM OPERATING INSTRUCTIONS</u>	13
<u>7. TROUBLESHOOTING</u>	13
7.1. STATUS INDICATIONS AND ERROR REPORTING.....	13
7.2. TROUBLESHOOTING A NON-OPERATING MICROINVERTER.....	14
<u>8. REPLACEMENT</u>	15
<u>9. TECHNICAL DATA</u>	15
<u>10. WIRING DIAGRAMS</u>	19
<u>11. MONITORING PLATFORM</u>	23

LIST OF FIGURES

FIGURE 1 - 300G3/500G3/600G3/800G3/1000G3 MODELS.....	6
FIGURE 2 - 1300G3/1600G3/1800G3/2000G3.	7
FIGURE 3 - INSTALLING THE AC BRANCH CIRCUIT JUNCTION BOX.	9
FIGURE 4 - 300G3/500G3 (1MPPT) AND 600G3/800G3/1000G3 (2MPPT) MOUNTING.....	10
FIGURE 5 - 1300G3/1600G3/2000G3 (4MPPT) MOUNTING.	10
FIGURE 6 – 300G3/500G3 (1MPPT) AND 600G3/800G3/1000G3 (2MPPT) CONNECT IN PARALLEL.	11
FIGURE 7 – 1300G3/1600G3/2000G3 (4MPPT) CONNECT IN PARALLEL.	11
FIGURE 8 - L, N, AND PE CONNECTIONS.....	12
FIGURE 9 - INSTALLING AC PROTECTIVE END CAP.....	12
FIGURE 10 - CONNECTING THE MICROINVERTER TO THE SOLAR MODULES.	12

1. IMPORTANT SAFETY INSTRUCTIONS

This manual contains important instructions to follow when installing and maintaining the Photovoltaic Grid-connected Inverter (Microinverter). The following symbols appear throughout this document to indicate situations that might pose a risk to the user. These should be followed carefully, in order to reduce the risk of electrical shock and ensure the safe installation and operation of the Microinverter.

Specifications are subjected to change without notice - please ensure you are using the latest manual found at the manufacturer website.

WARNING:

This box indicates a situation where failure to follow instructions may cause a serious hardware failure or personnel danger if not followed appropriately. Use extreme caution when performing this task.

NOTE:

This box indicates information that is important for optimised Microinverter operation. Follow these instructions strictly.

- **DO NOT** disconnect the PV module from the Microinverter without disconnecting the AC power.
- Only qualified professionals should install and/or replace the Microinverters.
- Perform all electrical installations in accordance with local electrical codes/guidelines.
- Before installing or using the Microinverter, please read all instructions and cautionary markings in the technical documents and the Microinverter system and the solar-array.
- Be aware that the body of the Microinverter is the heat sink and can reach a temperature of 80°C. To reduce the risk of burns, do not touch the body of the Microinverter.
- **DO NOT** attempt to repair the Microinverter. If it fails, contact technical support to obtain an RMA number and start the replacement process. Damaging or opening the Microinverter will void the warranty.

CAUTION:

The external protective earthing conductor is connected to the inverter protective earthing terminal through the AC connector. When connecting, connect the AC connector first to ensure the inverter earthing, then make the DC connections. When disconnecting, disconnect the AC by opening the branch circuit breaker first but maintain the protective earthing conductor in the branch circuit breaker connect to the inverter, then disconnect the DC inputs.

- In any circumstance, **DO NOT** connect DC input when the AC connector is unplugged.
- Please install isolation switching devices on the AC side of the inverter.

Qualified Personnel:

A qualified person is one who has skills and knowledge related to the construction and operation of the electrical equipment and has received safety training on the hazards involved. It is authorized to energise, ground, and tag equipment systems and circuits in accordance with established safety procedures. The inverter and end-using system may only be commissioned by qualified personnel.





1.1. RADIO INTERFERENCE STATEMENT



CE EMC Compliance: The equipment can comply with CE EMC regulations, which are designed to protect against harmful interference in a residential installation. The equipment can give out radio frequency energy and this might cause harmful interference to radio communications if the instructions presented below are not followed when installing the equipment. If this equipment causes harmful interference to radio or television reception, the following measures might resolve the issues:

- a) Relocate the receiving antenna and keep it well away from the equipment.
- b) Consult the dealer or an experienced radio / TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

1.2. SYMBOLS

Can be OEM	Trademark.
	Caution, risk of electric shock.
	Caution, risk of burn - Do not touch.
	Caution, hot surface.
	Symbol for the marking of electrical and electronics devices according to Directive 2002/96/EC. Indicates that the device, accessories and the packaging must not be disposed as unsorted municipal waste and must be collected separately at the end of the usage. Please follow Local Ordinances or Regulations for disposal or contact an authorized representative of the manufacturer for information concerning the decommissioning of equipment.

	<p>CE mark is attached to the solar inverter to verify that the unit follows the provisions of the European Low Voltage and EMC Directives.</p>
	<p>Refer to the operating instructions.</p>
<p>Qualified personnel</p>	<p>Person adequately advised or supervised by an electrically skilled person to enable him or her to perceive risks and to avoid hazards which electricity can create. For the purpose of the safety information of this manual, a "qualified person" is someone who is familiar with requirements for safety, refrigeration system and EMC and is authorized to energize, ground, and tag equipment, systems, and circuits in accordance with established safety procedures. The inverter and endues system may only be commissioned and operated by qualified personnel.</p>

2. MICROINVERTER SYSTEM INTRODUCTION

The Microinverter is used in utility-interactive grid-tied applications and it is comprised of two key elements: the Microinverter and the router.




Figure 1 - 300G3/500G3/600G3/800G3/1000G3 models.




Figure 2 - 1300G3/1600G3/1800G3/2000G3.

NOTE:

If the wireless signal in the area where the Microinverter is weak, it is necessary to add a WIFI signal booster at a suitable place between the router and the Microinverter.

This integrated system improves safety, maximizes solar energy harvest, increases system reliability, and simplifies solar system design, installation, maintenance, and management.

2.1. MICROINVERTERS MAXIMIZE PV ENERGY PRODUCTION

Each PV module has individual Maximum Peak Power Tracking (MPPT) controls, which ensures that the maximum power is exported to the utility grid regardless of the performance of the other PV modules in the array. When PV modules in the array are affected by shade, dust, orientation, or any situation in which one module underperforms compared with the other units, the Microinverter ensures peak performance from the array by maximising the performance of each module within the array.

2.2. MORE RELIABLE THAN CENTRALIZED OR STRING INVERTERS

The distributed Microinverter system ensures that no single point of system failure exists across the PV system. Microinverters are designed to operate at full power at ambient outdoor temperatures of up to 149°F (65°C). The inverter housing is designed for outdoor installation and complies with the IP65 environmental enclosure rating

2.3. INSTALLATION - SIMPLICITY

You can install individual PV modules in any combination of Module quantity, orientation, different type, and power rate. The Ground wire (PE) of the AC cable is connected to the chassis inside of the Microinverter, potentially eliminating the installation of grounding wire (check local regulation).

Data collection adopts internal WIFI. A wireless router is needed near the Microinverter. When the installation of the Microinverter is complete, configure a wireless router with internal WIFI (refer to the WIFI user manual). The data will be uploaded automatically. Users can monitor and manage the Microinverter through the corresponding website or APP.

3. MICROINVERTER INTRODUCTION

Microinverters connect with the single-phase grid, and we can also use multiple Microinverters in the form of a single-phase grid to achieve a three-phase grid.

For more information, please see the Technical Data page (P17~20) of this manual.

Model Number	AC Grid	Max. # Per Branch
SUN300G3-EU-230	50/60Hz, 230 V	17 for 45A breaker
SUN500G3-EU-230	50/60Hz, 230 V	10 for 45A breaker
SUN600G3-EU-230	50/60Hz, 230 V	8 for 45A breaker
SUN800G3-EU-230	50/60Hz, 230 V	6 for 45A breaker
SUN1000G3-EU-230	50/60Hz, 230 V	5 for 45A breaker
SUN1300G3-EU-230	50/60Hz, 230 V	4 for 45A breaker
SUN1600G3-EU-230	50/60Hz, 230 V	4 for 45A breaker
SUN1800G3-EU-230	50/60Hz, 230 V	3 for 45A breaker
SUN2000G3-EU-230	50/60Hz, 230 V	3 for 45A breaker

4. MICROINVERTER SYSTEM INSTALLATION

A PV system using Microinverters is simple to install. Each Microinverter easily mounts on the PV racking, directly beneath the PV module(s). Low voltage DC wires connect from the PV module directly to the Microinverter, eliminating high DC voltage risk. Installation MUST comply with local regulations and technical rules.

Special Statement! An AC Ground-Fault Circuit Interrupter (GFCI) should not be used to protect the dedicated circuit to the Microinverter even though it is an outside circuit. None of the small GFCI devices (5~30mA) are designed for back feeding and will be damaged if back feeding occurs. In a similar manner, AC Arc-Fault Circuit Interrupter (AFCI) have not been evaluated for back feeding and may be damaged if back feed occurs with the output of a PV inverter.

WARNING:

- Perform all electrical installations in accordance with local electrical codes.
- Be aware that only qualified professionals should install and/or replace Microinverters.
- Before installing or using a Microinverter, please read all instructions and warnings in the technical documents, as well as on the Microinverter system itself and the PV array.
- Be aware that the installation of this equipment includes the risk of electric shock.
- Do not touch any live parts in the system, including the PV array, when the system has been connected to the electrical grid.

NOTE:

Strongly recommend installing Surge Protection Devices in the dedicated meter box.

4.1. ADDITIONAL INSTALLATION COMPONENTS

- AC Male and Female Interconnection Connectors (sold separately)
- Sealing end caps (sold separately)

4.2. REQUIRED PARTS AND TOOLS (USER SUPPLIED)

- An AC connection junction box
- Mounting hardware suitable for module racking
- Sockets and wrenches for mounting hardware
- Continuous grounding conductor and grounding washers
- A Phillips screwdriver
- A torque wrench

5. INSTALLATION PROCEDURES


Step 1 – Install the AC branch circuit junction box

Figure 3 - Installing the AC branch circuit junction box.

- Install an appropriate junction box at a suitable location on the PV racking system (typically at the end of a branch of modules).
- Connect the open wire end of the AC cable into the junction box using an appropriate gland or strain relief fitting.
- Wire the conductors of the AC(230/400Vac): L - red; N - black; PE - yellow-green.
- Connect the AC branch circuit junction box to the point of utility Interconnection.

WARNING:

Wiring colour codes can be different according to local regulations. Check all the wires of the installation before connecting to the AC cable to be sure they match. Wrong cabling can damage the microinverters irreparably. The warranty does not cover such an issue.

Step 2 – Attach the Microinverters to the racking or the PV module frame

- Mark the location of the Microinverter on the rack, with respect to the PV module junction box or any other obstructions.
- Mount one Microinverter at each of these locations using hardware recommended by your module racking vendor.




Figure 4 - 300G3/500G3 (1MPPT) and 600G3/800G3/1000G3 (2MPPT) mounting.




Figure 5 - 1300G3/1600G3/2000G3 (4MPPT) mounting.

WARNING:

Prior to installing any of the microinverters, verify that the utility voltage at the point of common connection matches the voltage rating on the microinverter label.

WARNING:

Do not place the inverters (including DC and AC connectors) to be exposed to the sun, rain or snow, and this includes the gap between modules. Allow a minimum of 3/4 (1.5cm.) between the roof and the bottom of the Microinverter to allow proper airflow.

Step 3 – Connect the microinverters in parallel




Figure 6 – 300G3/500G3 (1MPPT) and 600G3/800G3/1000G3 (2MPPT) connect in parallel.




Figure 7 – 1300G3/1600G3/2000G3 (4MPPT) connect in parallel.

- Check the Microinverter technical data in Page 5 for the maximum allowable number of Microinverters on each AC branch circuit.
- Plug the male AC connector of the Microinverter into the female connector to get it connected.AC connector interface as follows.




Figure 8 - L, N, and PE connections.

WARNING:

DO NOT exceed the maximum number of microinverters in an AC branch circuit, as displayed on Page 5 of this manual.

Step 4 – Install an AC cable protective end cap at the end of the AC cable




Figure 9 - Installing AC protective end cap.

Step 5 – Connect the microinverter to the PV modules




Figure 10 - Connecting the microinverter to the solar modules.

NOTE:

When plugging in the DC cables, if AC is already available, the microinverter should immediately blink red light and start work within the set time (default 60 seconds). If AC is not available, the red light will blink 3 times quickly and repeat after one second until AC is connected.

6. MICROINVERTER SYSTEM OPERATING INSTRUCTIONS

To operate the microinverter PV system:

1. Turn ON the AC circuit-breaker on each microinverter AC branch circuit.
2. Turn ON the main utility-grid AC circuit-breaker. Your system will start producing power after a one-minute waiting time.
3. The units should start blinking red one minute after turning on the AC circuit-breaker. Then blue led blinking. This means they are producing power normally. The faster blinking of the blue led means more power generated.
4. Configure the internal WIFI module according to its user manual.
5. The Microinverters will start to send performance data over WIFI module to the network every 5 minutes. It enables customers to monitor the performance data of each Microinverter through a website and APP.

NOTE:

When AC power is applied but the Microinverter has not started up, about 0.1A current and 25VA(W) power for each Microinverter may be measured by a power meter. This power is 'reactive power', not consume from the utility grid.

7. TROUBLESHOOTING

Qualified personnel can use the following troubleshooting steps if the PV system does not operate correctly.

7.1. STATUS INDICATIONS AND ERROR REPORTING

■ Startup LED

One minute after DC power is first applied to the Microinverter, one short red blink indicates a successful microinverter startup sequence, be equal or greater than two short red blinks after DC power is first applied to the microinverter indicate a failure during microinverter setup.

■ Operation LED

Flashing Slow Blue - Producing small power

Flashing Fast Blue - Producing big power

Flashing Red - Not producing power

Red blinking two times - AC low-voltage or high-voltage

Red blinking three times - Grid failure

■ GFDI Error

A red LED blinking four times indicates the Microinverter has detected a Ground Fault Detector Interrupter (GFDI) error in the PV system. Unless the GFDI error has been cleared, the LED will remain four times blinking.

■ Other Faults

All other faults can be reported to the website and APP.

WARNING:

Never disconnect the DC wire connectors under load. Ensure that no current is flowing in the DC wires prior to disconnecting. An opaque covering may be used to cover the module prior to disconnecting the module.

7.2. TROUBLESHOOTING A NON-OPERATING MICROINVERTER

There are two possible overall areas of trouble:

- a) The Microinverter itself may be having problems.
- b) The Microinverter itself is working fine, but the communication between Microinverter and network has a problem. The items below refer to Microinverter issues, not communication issue.

A quick way to tell whether the issue is the Microinverter or the communication problem:

1. Diagnosing from the Microinverter: A red LED either blinking or constant on the Microinverter, or no light at all means it is definitely the Microinverter problem.
2. 0 watts, or 2 watts: possibly a Microinverter problem

Diagnosing from the network:

1. No-Data-Display: The website and APP does not display any data. Check the network configuration.
2. Only display microinverter is online but no data. This may be because the server is updating

To troubleshoot a non-operating Microinverter, follow the steps below in order:

1. Verify the utility voltage and frequency are within ranges shown in the Technical Data section of this manual.
2. Check the connection to the utility grid. Disconnect AC firstly, then disconnect DC and make sure the utility grid voltage can be measured at AC connector. Never disconnect the DC wires while the Microinverter is producing power. Re-connect the DC module connectors and watch for three short LED flashes.

3. Check the AC branch circuit interconnection between all the microinverters. Verify each inverter is energized by the utility grid as described in the previous step.
4. Make sure that any AC breaker is functioning properly and are closed.
5. Check the DC connections between the Microinverter and the PV module.
6. Verify the PV module DC voltage is within the allowable range shown in the Technical Data of this manual.
7. If the problem still persists, please contact technical support.

WARNING:

Do not attempt to repair the Microinverter. If troubleshooting methods fail, please call for Technical Support.

8. REPLACEMENT

Follow the procedure below to replace a failed Microinverter:

- a) Disconnect the Microinverter from the PV Module, in the order shown below:
 1. Disconnect the AC by turning off the branch circuit-breaker.
 2. Disconnect the AC connector of the microinverter.
 3. Cover the module with an opaque cover.
 4. Disconnect the PV module DC wire connectors from the Microinverter.
 5. Remove the Microinverter from the PV array racking.
- b) Remove the opaque cover and install a replaced Microinverter to the bracket.

Remember to observe the flashing LED light as soon as the new Microinverter is plugged into the DC cables.
- c) Connect the AC cable of the replacement Microinverter.

9. TECHNICAL DATA

WARNING:

- Be sure to verify the voltage and current specifications of your PV module match with those of the Microinverter. Please refer to the datasheet or user manual.
- You must match the DC operating voltage range of the PV module with the allowable input voltage range of the Microinverter.
- The maximum open-circuit voltage of the PV module must not exceed the specified maximum input voltage of the inverter.

300G3/500G3/600G3 Specification:

Model	SUN300G3 -EU-230	SUN500G3 -EU-230	SUN600G3 -EU-230
Input Data (DC)			
Recommended input power(STC)	210~400W	210~600W	210~400W
Maximum input DC voltage	60V		
MPPT Voltage Range	25~55V		
Operating DC Voltage Range	20~60V		
Max DC short circuit current	16A	16A	16A
Max input current	10.5A×1	12.5A×1	10.5A×2
Output Data (AC)			
Rated output Power	300W	500W	600W
Maximum output power	330W	550W	660W
Maximum output Current	1.4A	2.4A	2.9A
Nominal voltage / range	230V / 184-265V		
Nominal frequency	50/60Hz		
Extended frequency / range	45~55Hz/ 55~65Hz		
Power factor	> 0.99		
Maximum unit per branch	17	10	8
Max. allowed altitude operating	< 4000m		
Max.inverter backfeed current to the array	0A		
Max output fault current	10A		
Max output overcurrent protection	1.4A	2.4A	2.9A
Efficiency			
CEC weighted efficiency	95%		
Peak inverter efficiency	96.5%		
Static MPPT efficiency	99%		
Night time power consumption	50mW		
Mechanical Data			
Ambient temperature range	-40 °C ~ +65 °C		
Dimensions(W×H×D mm)	212×229×40 mm (Does not include cable)		
Weight (kg)	3.5		
Cooling	Natural Convection - No Fans		
Enclosure environmental rating	IP67		
Protective class	Class III		
Features			
Compatibility	Compatible with 60,72 cell PV modules		
Communication	Power line / WiFi / Zigbee		
Compliance	EN50549,VDE0126,VDE4105,IEC62109,CE,INMETRO		
Warranty	10 Years		

800G3/1000G3 Specification:


Model	SUN800G3 -EU-230	SUN1000G3 -EU-230
Input Data (DC)		
Recommended input power(STC)	210~600W	
Maximum input DC voltage	60V	
MPPT Voltage Range	25~55V	
Operating DC Voltage Range	20~60V	
Max DC short circuit current	16A	
Max input current	12.5A×2	
Output Data (AC)		
Rated output Power	800W	1000W
Maximum output power	880W	1100W
Maximum output Current	3.8A	4.8A
Nominal voltage / range	230V / 184-265V	
Nominal frequency	50/60Hz	
Extended frequency / range	45~55Hz/ 55~65Hz	
Power factor	>0.99	
Maximum unit per branch	6	5
Max. allowed altitude operating	<4000m	
Max.inverter backfeed current to the array	0A	
Max output fault current	10A	
Max output overcurrent protection	3.8A	4.8A
Efficiency		
CEC weighted efficiency	95%	
Peak inverter efficiency	96.5%	
Static MPPT efficiency	99%	
Night time power consumption	50mW	
Mechanical Data		
Ambient temperature range	-40 °C ~ +65 °C	
Dimensions(W×H×D mm)	212×229×40 mm (Does not include cable)	
Weight (kg)	3.5	
Cooling	Natural Convection - No Fans	
Enclosure environmental rating	IP67	
Protective class	Class III	
Features		
Compatibility	Compatible with 60,72 cell PV modules	
Communication	Power line / WiFi / Zigbee	
Compliance	EN50549,VDE0126,VDE4105,IEC62109,CE,INMETRO	
Warranty	10 Years	

1000G3/1300G3/1600G3/1800G3/2000G3 Specification:


Model	SUN1300G3 -EU-230	SUN1600G3 -EU-230	SUN1800G3 -EU-230	SUN2000G3 -EU-230
Input Data (DC)				
Recommended input power(STC)	210~400W	210~600W	210~600W	210~600W
Maximum input DC voltage	60V			
MPPT Voltage Range	25~55V			
Operating DC Voltage Range	20~60V			
Max DC short circuit current	16A			
Max input current	10.5A×4	12.5A×4	12.5A×4	12.5A×4
Output Data (AC)				
Rated output Power	1300W	1600W	1800W	2000W
Maximum output power	1430W	1760W	1980W	2200W
Maximum output Current	6.2A	7.7A	8.6A	9.6A
Nominal voltage / range	230V / 184-265V			
Nominal frequency	50/60Hz			
Extended frequency / range	45~55Hz/ 55~65Hz			
Power factor	>0.99			
Maximum unit per branch	4	4	3	3
Max. allowed altitude operating	<4000m			
Max.inverter backfeed current to the array	0A			
Max output fault current	10A			
Max output overcurrent protection	6.2A	7.7A	8.6A	9.6A
Efficiency				
CEC weighted efficiency	95%			
Peak inverter efficiency	96.5%			
Static MPPT efficiency	99%			
Night time power consumption	50mW			
Mechanical Data				
Ambient temperature range	-40 °C ~ +65 °C			
Dimensions(W×H×D mm)	212×229×40 mm (Does not include cable)			
Weight (kg)	3.5			
Cooling	Natural Convection - No Fans			
Enclosure environmental rating	IP67			
Protective class	Class III			
Features				
Compatibility	Compatible with 60,72 cell PV modules			
Communication	Power line / WiFi / Zigbee			
Compliance	EN50549,VDE0126,VDE4105,IEC62109,CE,INMETRO			
Warranty	10 Years			

10. WIRING DIAGRAMS


Sample Wiring Diagram Three Phase




Sample Wiring Diagram Single Phase



Sample Wiring Diagram Three Phase



Sample Wiring Diagram Single Phase



11. MONITORING PLATFORM

This series Microinverter has built-in WIFI modular, which is able to connect the router directly. For WIFI configuration, please check the manual of “Built-in WIFI Modular Microinverter WIFI Configuration Manual”.

Web monitoring address:

<https://pro.solarmanpv.com>; (for Solarman distributor account)

<https://home.solarmanpv.com> (for Solarman end-user account)

For a mobile phone monitoring system, scan the QR code to download the APP. Also, you could find it by searching “Solarman” in App Store or Google Play.



IOS/Android system for
plant owner account



IOS/Android system for
distributor account



Global Tech China Ltd, 3 Floor, Wai Yip Industrial Building.171 Wai Yip Street,
Kwun Tong, Kowloon, Hong Kong.
Tel: +852 2884 4318 Fax: +8522884 4816
www.sunsynk.com / sales@globaltech-china.com / www.globaltechhk.com